

# Colorimeter for leaf,petal,etc. LeafEye

<http://www.hi-ho.ne.jp/hasshokukou/>

←Japanese Only



**LeafEye =**

Conventional Colorimeter




+

The function which measures the color of a leaf/petal/etc.(high light transmittance material)


+

The function which performs the automatically judging of the RHS/JHS color chart code

Color Chart  
Code Identify



CIE-L\*a\*b\* Diagram



RGB Plot

## Feature

1. It is possible to measure the color of a leaf/petal.  
\*LeafEye can simulate ambience light under natural environment.  
\*The conventional colorimeter cannot measure the color of a leaf/petal equivalent to measurement by viewing.
2. It is possible to search a code automatically from RHS/JHS color chart table.
3. It is not necessary to adjust.
4. It is portable.  
\* Battery can be used. \* LE-Card can be used.

### Basic Set

- Control box
- Probe
- Software(for Windows)
- AC Adapter(Power supply)
- Cable
- Manual

### Option

- LE-Card
- LE-Card with JHS Permission key
- Note PC
- USB-Serial Converter

### Option

- Battery 006P(9V)

Distributor SCETI K.K.  
Kasumigaseki Place, 3-6-7 Kasumigaseki,  
Chiyoda-ku, Tokyo 100-0013 JAPAN  
TEL; +81(0)3-5510-2347  
FAX; +81(0)3-5510-0134  
E-mail: [exp-pet@sceti.co.jp](mailto:exp-pet@sceti.co.jp) URL: [www.sceti.co.jp/export/](http://www.sceti.co.jp/export/)

Manufacturer LLC.HASSHOKUKOU